

Take the hassle out of wiring auxiliary lights to your vehicle with

3 EASY STEPS

- Connect headlight adaptor, mount relay and connect power cables
- Run wires to driving lights and terminate, connect LED position lights to park light feed
- Run switch cable into cabin, mount and connect switch

Quick Fit Harness Features:

Universal quick fit

- Internal electronics suits ALL Aust, Euro and Japanese positive or negative switching systems
- No test equipment required for correct connection and operation
- No polarity checking or switching required
- Heavy duty quick fit headlight adaptor, suits all H4 headlight connectors. (For other than H4 simply remove and connect two wires)
- Can be adapted for fog light or other fitment
- Relay fitted with fuse 12V@30A or 24V@15A

Heavy duty harness

- Harness made of heavy cables to reduce voltage drop and increase light performance
- Three wires to lights to cater for LED position lamps
- Red: Pos | Black: Earth | Yellow: Park light
- Pre-wired power cables for positive & earth
- Wiring colour coded with black tubing to blend in with existing wiring

Easy switch installation with complete functionality

- Switch connector not installed allows easy passing through fire wall
- Switch cable pre-terminated for easy connection to switch
- Small surface mount switch enables quick fitment to ALL vehicles types
- Small push button switch allows low profile installation
- No mounting holes required for switch allows for easy removal
- LED power indicators. RED: High beam power ON. GREEN driving lights ON

Xray Vision Quick Fit Heavy Duty Wiring Harness



Part Numbers: DLWIRE-KIT-12V | DLWIRE-KIT-24V

BDL09102P

