

TPWKIT-012
TPWKIT-013
TPWKIT-014

- SIMPLE TO INSTALL
- REDUCES FITMENT TIME
- INCLUDES EVERYTHING REQUIRED TO SUPPORT THE INSTALLATION OF A TOW-PRO
- INCLUDES FITTING INSTRUCTIONS
- PROTECTS VEHICLE FROM INCORRECT WIRING

Available
April 2020.

Old	Vehicle	New
TPWKIT-002	Colorado	TPWKIT-013
TPWKIT-003	Triton	TPWKIT-014
TPWKIT-004	Hilux	TPWKIT-013
	Fortuner	TPWKIT-013
	Prado	TPWKIT-013
TPWKIT-005	LC200	TPWKIT-014
TPWKIT-006	Isuzu	TPWKIT-013
TPWKIT-007	Kluger	TPWKIT-013
TPWKIT-008	Navara	TPWKIT-014
TPWKIT-009	Pajero	TPWKIT-013
TPWKIT-010	Amarok	TPWKIT-014
TPWKIT-011	Universal	TPWKIT-014
TPWKIT-012	Ranger/Everest	TPWKIT-012

NEW PRODUCT RELEASE

Tow Pro Wiring Kits

REDARC has released a simplified range of Tow-Pro Wiring kits supporting the installation of the market-leading Tow-Pro Elite electric trailer brake controller into a wide range of vehicles.

By streamlining the range from 10 to 3 kits, customers can simplify their stockholding.

For each of the 3 kits, the interface to the Vehicle Stop Lamp signal is made at the Trailer socket; this provides a consistent reliable source of the 12V signal indicating when trailer braking is required, and supports modern driver aids such as Autonomous Emergency Braking; Adaptive Cruise Control and collision avoidance where the vehicle brake signal may be generated from a number of different systems.

One of the three kits is unchanged – TPWKIT-012 – supporting Ford Ranger and Everest. The other two kits differ only in the provision of the length of the positive power connection.

In all 3 TPWKIT's, hardware and fitting instructions are included to deliver a quality and reliable outcome every time whilst protecting the integrity of the vehicle, avoiding the setting of fault codes or damage to sensitive electronics.

PART NUMBER	Description	Barcode
TPWKIT-012	Ford Ranger Wiring Kit	9338628005451
TPWKIT-013	Universal Tow-Pro Wiring Kit	9338628006014
TPWKIT-014	Universal Tow-Pro Extended Wiring Kit	9338628006021

