



A01-11016-1

PREFIX

A00: Air-O-Crimp
A01: Alloy Barb
A02: Beadlock Alloy
A03: Steel Beadlock
A04: Steel Reduced Beadlock

FIRST TWO DIGITS

11: Female Flare
12: Male Flare
13: Female O'Ring
14: Male O'Ring
17: Bulkhead Style
18: Male Insert O'Ring
19: Adaptors
20: Compressor Adaptor Fittings
21: Tube-O & Rotalok
22: VIR Conversion Fitting
23: Compressor Blocks
25: Gaskets
26: Misc. Adaptor & Orifice Tube
28: Compression Adaptors
29: Compression Fitting - Inch
30: Compression Fitting - Metric
58: Braze / Weld on Barb
61: Hose Splicer
62: Auxiliary A/C Tee
63: Splicers
64: R12 Service Adaptors
65: R132 Adaptors
66: Braze on Beadlock
83: Metric Adaptors
93: Female O'Ring - Metric
94: Male Insert O'Ring - Metric

THIRD DIGIT

0: Straight
1: 45°
2: 90°

FIFTH DIGIT

6: 16 Hose
Example: A00-13046: 12FTG to # 16 Hose

SUFFIX

-1: 1/4" R12 Service Valve
-3: R134a Quick Connect
-4: M10 Service Valve
-5: M12 Service Valve
-9: R134a High Side Port
-2: 3/16 R12 Service Valve
-SD: Short Drop

FOURTH DIGIT FOR ENGLISH THREADS

1: 6 FTG x 6 Hose
2: 8 FTG x 8 Hose
3: 10 FTG x 10 Hose
4: 12 FTG x 12 Hose
5: 6 FTG x 8 Hose
6: 8 FTG x 10 Hose
7: 10 FTG x 12 Hose
8: 8 FTG x 6 Hose
9: 10 FTG x 8 Hose
0: 12 FTG x 10 Hose

FOURTH DIGIT FOR METRIC THREADS

1: 5 FTG x 6 Hose
2: M16 FTG x 6 Hose
3: M18 FTG x 6 Hose
4: M20 FTG x 6 Hose
5: M20 FTG x 8 Hose
6: M22 FTG x 10 Hose
7: M24 FTG x 10 Hose
8: M27 FTG x 12 Hose