

ANV022GQ Connector


The Connector on the original alternator that JAS ANV022GQ replaces has a different pin configuration to the ANV022GQ. The physical plug is the same, and the "L" or warning light terminal is in the same position.

ANV022GQ only requires the L terminal to operate so there are no changes required to use the OE vehicle connector.




ANV022GQ

Original
Connector



ANV022GQ
Connector



L= Warning Light
D= Dummy terminal