



LED AMBER/WHITE WARNING MODULE

Installation Instructions

LV9620AW



Wiring Code :

Black wire : (Earth) or (-) connection

Red wire : Battery / IGN or (+) connection

Green wire : (Pattern Change & Synchronize) :

Connect Green wire to Battery / IGN or (+) connection for pattern change

Connect Green wires of all modules together for synchronization.

White wire : (Simultaneous or Alternating flash) :

Connect White wires together when grouping of multiple warning module applications


Lamp operating range : 10-30 Volts

Please ensure this lamp is installed and operated by qualified personal only

LED AMBER/WHITE WARNING MODULE

Installation Instructions

LV9620AW



LV9620AW: (Total 15 Patterns)

Pattern	Flash Mode	FPM	ms	Colour
1	Single Flash, ECE R65 Class 1	125	480	Amber
2	Single Flash, California Title 13	75	800	Amber
3	Double Flash	125	480	Amber
4	Quadruple Flash	125	480	Amber
5	Combination Single / Triple Flash	N/A	N/A	Amber
6	Combination Single / Quintuple Flash	N/A	N/A	Amber
7	Strobe	600	100	Amber
8	Single Flash, ECE R65 Class 1	125	480	White
9	Single Flash, California Title 13	75	800	White
10	Double Flash	125	480	White
11	Quadruple Flash	125	480	White
12	Combination Single / Triple Flash	N/A	N/A	White
13	Combination Single / Quintuple Flash	N/A	N/A	White
14	Strobe	600	100	White
15	Alternating Amber / White, Single Flash	N/A	N/A	Amber & White