

Switch Accessories

Round Hole Switch Panel

- Round Hole Switch Panels with 12.5mm Round Hole
- Suits: Toggle Switches



Part No.	Description	Pack Size
E52-7000	Single Hole	1
E52-7001	Double Hole	1
E52-7002	Triple Hole	1

Rectangle Hole Switch Panel

- Rectangle Hole Switch Panels with 29 x 11.55mm Hole
- Suits: Rocker Switches



Part No.	Description	Pack Size
E52-7003	Single Hole	1
E52-7004	Double Hole	1
E52-7005	Triple Hole	1

E61-82159-1 Rocker Switch Mounting Bezel

- End Rocker Switch Mounting Bezel
- Suits: 56027 & 58328 Series Switches
- Bezels can snap into a Panel / can be mounted with the Bracket Mounting
- Kit Part Number: [E61-87167-01-BP](#)



E61-82159-2 Rocker Switch Mounting Bezel

- Center Rocker Switch Mounting Bezel
- Suits: 56027 & 58328 Series Switches
- Bezels can snap into a Panel / can be mounted with the Bracket Mounting
- Kit Part Number: [E61-87167-01-BP](#)



E61-87167-01-BP Bracket Mounting Kit

- Use with Rocker Switch Mounting Bezel (82159 Series) to install the Rocker Switches under / on top of a Panel
- Snap together assembly
- Holds 2 to 6 Bezels (sold separately)
- Includes Brass Stabilizing Rods which Snap into Brackets



E61-98628 Blanking Plate

- Use with Rocker Switch Mounting Bezels (82159 Series)
- Face Dimensions: 1.91" x 0.96" (24.4 x 48.8mm)

