

Delco Alternator Tacho pick up point

20SI 21SI 22SI 25 SI 30SI 33SI 34SI 36SI 55SI Delco Alternators have an "R" Terminal that is generally connected to a phase point inside the Alternator which is a suitable place to pick up a Tacho signal.

The I Terminal can be used as a Warning Light Indicator but is not a traditional D+ Terminal in all cases so should not be relied upon to be an active terminal or back feed a warning light.

